



PLACE DOWNSTREAM STRUCTURE SUCH THAT POINT "B" IS APPROXIMATELY LEVEL WITH THE LOWEST GROUND ELEVATION OF THE UPSTREAM STRUCTURE

ROCK DITCH CHECK




NOTES:  
1. WHEN USED TO CONTROL SEDIMENT FROM STEEP SLOPES, ROCK CHECKS SHOULD BE PLACED AWAY FROM THE TOE OF A SLOPE FOR INCREASED HOLDING CAPACITY.

2. WHEN SEDIMENT FILLS THE AREA BEHIND THE SILT FENCE TO 1/2 THE HEIGHT OF THE ROCK CHECK, THE CONTRACTOR SHALL REMOVE THE SEDIMENT.



GRAVEL FILTER FOR AREA INLET




WATTLE & SILT FENCE SPACING TABLE	
SLOPE	MAXIMUM SPACING
1:1	10 FEET
2:1	20 FEET
3:1	30 FEET
4:1	40 FEET

NOTES:

1. INSTALL WATTLES GENERALLY PARALLEL TO THE CONTOURS
2. WATTLES SHALL BE INSPECTED REGULARLY, AND IMMEDIATELY AFTER A RUNOFF PRODUCING RAINFALL, TO ENSURE THEY REMAIN THOROUGHLY ENTRENCHED AND IN CONTACT WITH THE SOIL.
3. LIVE STAKES MAY BE USED FOR PERMANENT INSTALLATIONS.
4. WHEN SEDIMENT FILLS THE AREA BEHIND THE WATTLES TO 1/2 THE HEIGHT OF THE WATTLES, THE CONTRACTOR SHALL REMOVE THE SEDIMENT.
4. INSTALL WATTLES SNUGLY INTO THE TRENCH. ABUT ADJACENT WATTLES TIGHTLY, END TO END, WITHOUT OVERLAPPING THE ENDS.
5. PILOT HOLES MAY BE DRIVEN THROUGH THE WATTLE AND INTO THE SOIL, WHEN SOIL CONDITIONS REQUIRE.

WATTLE & SILT FENCE INSTALATION ON SLOPE



GRAVEL FILTER FOR CURB INLET

